





SCK GND

TP44 TP45 R40 TP48

3V3 TP40 PWDN

SDA SCL Cam\_VDD

USB\_ON/OFF

CLK2 DAT2

C34 C45 C5

TP49 SD\_VDD

SD 2.0

R64 R61

C65 C66

C68 C69

SIM2

C74 C73

R52 R53

RST2 VDD2

D2 R18 D3 R19 D7 D4 R20 D5 R21 R22 D6 SCL L12 L13 R10 R9 R16 SIM1

- VDD
- DAT
- CLK
- RST

TP8 TP22 TP12 TP11 TP10 TP9 TP13

R63 R60 C72 C71 C70 C69 R57 R59 R56 R58

RST2 VDD2

- DAT2
- DAT1
- DAT3
- CLK
- CMD
- VDD

TP14 TP18 TP16 TP15

C25 L3 C30 L5 C26 C31 C28 C27 R27 R28 R29 R34 C24 C32 C23 C33

C53 C5 C57 C6 C55 C8 C2

U16

Q6 Q7